





Dimensions & Terminals

INSTALLATION TIP:

- It is forbidden to dismantle and change the product by oneself. disassembly and modification of the product may cause accidents, fire or electric shock.
- This product is recommended for use in automotive environments with a DC voltage range of 12-14.4 v beyond which failure may occur.
- Before wiring, be sure to disconnect the cable from the Power Terminal First, other-wise it is easy to cause short circuit and cause fire.
- Do not use the screws and nuts in the brake system when installing and grounding cables. This will cause the brake system to fail and cause an accident.
- Protect the cable from damage caused by pulling, cutting and short-circuiting.



Connection Indicator Diagram

Technical Parameter

Capacitance	1,000,000 μ F
Input Voltage	10V-16V
Output Voltage	10V-16V
Fuse	25A $\times$ 4
Weight	2.9Kg
Dimensions	214 $\times$ 208 $\times$ 50mm