





### Dimensions & Terminals

#### Bluetooth Connection Tutorial

When the amplifier is in working mode, the phone can search for the device name of "CAR\_DSP\_C5.2" through Bluetooth function, and click this option to perform Bluetooth pairing.

### INSTALLATION TIP:

- It is forbidden to dismantle and change the product by oneself. disassembly and modification of the product may cause accidents, fire or electric shock.
- This product is recommended for use in automotive environments with a DC voltage range of 12-14.4 v beyond which failure may occur.
- Before wiring, be sure to disconnect the cable from the Power Terminal First, other-wise it is easy to cause short circuit and cause fire.
- Do not use the screws and nuts in the brake system when installing and grounding cables. This will cause the brake system to fail and cause an accident.
- Protect the cable from damage caused by pulling, cutting and short-circuiting.



Connection Indicator Diagram

|                    |                             |                           |                            |
|--------------------|-----------------------------|---------------------------|----------------------------|
| Input              | USB lossless playback       | Output Power(MAX)         | 65W×4ch+50W×2ch            |
|                    | 2-channel low level input   | Frequency Response        | 20Hz~20KHz                 |
|                    | 4-channel high level input  | DSP Frequency Sampling    | 48KHz                      |
|                    | Optical input               | Signal to Noise Ratio     | 105dB                      |
|                    | Coaxial Input               | Total Harmonic Distortion | <0.01% (low level output)  |
| Output             | 6-channel high level output |                           | <0.03% (high level output) |
|                    | 8-channel low level output  | Bluetooth Version         | Bluetooth 5.0              |
| RCA Output Voltage | 2.35Volts                   | Operating Voltage         | 10-16 Volts                |